



APPLICATION MANUAL

PRECAUTIONS:

- Make sure the vehicle's tires have been washed and decontaminated.
- For best results, wait 10 to 15 minutes in between layers.
- Check the humidity and the temperature of both the surface & surrounding area. (60°F +).
- Do not apply the coating in direct sunlight, on a hot surface or under a heat lamp.
- Test product on an inconspicuous area before applying.
- Work in a ventilated area, and use gloves.
- Keep away from children.
- Discard Applicators immediately after use.
- We recommend having various light sources during application.



STEP #1

Shake
TRIM & TIRE
Before Use.



STEP #2

Apply a small amount of product to a **TIRE PAD** or **BLACK FOX APPLICATOR**



STEP #3

Apply the product evenly.



STEP #4

For a matte finish, apply a thin layer.
For a glossier finish, apply a thick layer.



STEP #5

Wipe away excess.



STEP #6

Wait 10 minutes for the surface to dry.